



Pos.	Description	Part-No.	Qty.	Pos.	Description	Part-No.	Qty.
1	left basic plate	H03-2GL-*	1	25	holder	SPS-03-B	1
2	right basic plate	H03-2GR-*	1	26	gear arm	SA01-*	1
3	left adjusting plate	UV01L-*	1	27	screw	M8x20ISO7380	4
4	right adjusting plate	UV01R-*	1	28	screw	M6x16DIN7991	2
5	gear lever bearing	UL01L-*	1	29	brake application pin	BR01	1
6	brake lever bearing	UL01R-*	1	30	screw	M5x10DIN7991	1
7	gear lever	US02-*	1	31	screw	M5x8ISO7380	4
8	brake lever	UB02-*	1	32	bolt	M8x40 DIN912	3
9	gear lever toe piece	UTR02	1	33	bolt	M6x30 ISO7380	1
10	brake lever toe piece	UTR01	1	34	bolt	M4x8 DIN912	1
11	left heel protector	CAR 01L	1	35	nut	M6-S	2
12	right heel protector	CAR01R 6-40	1	36	ball and socket bearing	GAKFR6	1
13	footrest	UF01-*	2	37	screw	M8x30DIN7991	4
14	holder brake cylinder	UHB25-*	1	38	screw	M6x10 ISO7380	1
15	gear shaft	USW09-*	1	39	screw	M6x25ISO7380	2
16	ball and socket bearing	GAKFL6	1	40	nut	M8-DIN934	1
17	brake cylinder adapter	UAD 02-23	1	41	spring	DF-1,2x11x30,2	1
18	holder for stopp light	BLS 02	1	42	washer	ULS 8,4	3
19	adapter pin	BO 01	1	43	conical nipple	DR-10	4
20	split pin	Spl 1,6	1	44	banjo bold	BB-10-1-25	1
21	washer	ULS 6,4	2	45	screw	M6x16 ISO7380	2
22	srew	M8x40 DIN7991	2	46	screw	M6x40 DIN7991	1
23	holder	HA03	1	47	screw	M6x20 DIN7991	1
24	collar	DS20-8-4	4	48	Vielzweckklemme	VZK-15	1

\* = Farbe/colour; G= gold / t= titan/titanium / B= schwarz/black