



	ATTACHED PARTS/part no.	QTY.
1	left basic plate H03-2GL-*	1
2	right basic plate H03-2GR-*	1
3	left adjusting plate UV 01 L-*	1
4	right adjusting plate UV 01 R-*	1
5	gear lever bearing UL 01 L-*	1
6	brake lever bearing UL 04 R-*	1
7	gear lever US 02-*	1
8	brake lever UB 02-*	1
9	gear lever toe piece UTR 02	1
10	brake lever toe piece UTR 01	1
11	left heel protector CAR 01 L	1
12	right heel protector CAR 01 R 6-45	1
13	footrest UF 01	2
14	holder for brake cylinder UHB 05-*	1
15	reversing holder UM B01-*	1
16	Gear shaft long USW 08- *	1
17	Gear shaft short USW 06-*	1
18	Reversing lever USU 01-*	1
19	aluminum collar DS 20-8-8	2
20	aluminum collar DS 12-6-9	1
21	Gear arm (without picture) SA 01-*	1
22	holder for stop light switch BLS 03	1
23	Ball and socket bearing right GAKFR 6	2
24	Ball and socket bearing left GAKFL 6	2
25	Brake cylinder adapter UAD 02-30	1
26	adapter pin BO 01	1
27	Washer ULS 6,4	1
28	split pin Spl 1,6	1
29	Spring FE 80	1



need for part no.	attached parts	qt y.
13	flat head bolt M8X 40	2
1+2	flat head bolt M8X 30	4
7+8+9+10	flat head bolt M6X 16	4
22	flat head bolt M5X 10	1
3+4	button head bolt M8X 40	4
18	button bolt head M8X 20	1
23	button head bolt M6X 30	1
14	button head bolt M6X 20	2
23	button head bolt M6X 16	1
	M8 washer ( thick)	
14	M6 washer ( thick)	2
21	Bolt M6x40 ISO 7380	1
21	Collar DS 12-6-20	1

-\* Colour/Farbe G = gold / T = titanium / B = black